

Preference

Features

BLF Settings

Line Settings

Date&Time

Tones

Voice

SMS

Action URL

Softkey Layout

TR069

SIP

BLF Selected Type

Default

Index	Current Call Status	BLF Status Text	BLF Led Mode
1	Idle	terminated	Solid Green
2	Incoming Call	early	Flashing Red 0.1s
3	Dialing	confirmed	Solid Red
4	Talking	confirmed	Solid Red
5	Hold	confirmed	Solid Red
6	Parked	confirmed	Solid Red
7	Off Line	unknown	Led Off

SaveSet

Cancel

NOTE

Current Call Status:

The monitored user's call status

BLF Status Text:

The Key word of BLF notify

BLF Led Mode:

The Led Flashing mode which you want